



## EXTERIOR DOMESTIC / COMMERCIAL MARINE or PUBLIC TRANSPORT BUS – TRAIN GLASS

Water Stain Doctor™ Full Strength IP Paste has been proven beyond doubt to remove mineral attachment and water spot staining on Glass with minimal negative effect.

An advisory, training and induction VIDEO can be viewed here:

<https://www.youtube.com/watch?v=qw7jnnYtfUo>

When using glass restore paste for EXTERIOR Window glass water spot removal, **ONLY USE** A SOFT FOAM PAD, or a soft BLUE ICE Pad - (These pads are around 5-7 inch diameter and should affix to the Velcro power drill disc)

You can generally buy smaller pads from an automotive supplier like Super Cheap/ Repco. Larger commercial 7 inch pads are available thru our online shop!

- \*\* DO USE PLENTY OF WATER – Keep paste whetted
- \*\* ALWAYS USE PAD ON LOW SPEED
- \*\* DO NOT use a pad that is too harsh or stiff especially if NOT Hardened or Toughened glass
- \*\* DO NOT TRY TO RESTORE GLASS IN DIRECT SUNLIGHT
- \*\* DO NOT OVER POLISH – Use your finger thru whetted paste to confirm restore
  
- \*\* **DO WATCH** our online video clips from our web site, and from our YOU TUBE channel

This paste is precisely the same recipe we ourselves utilise and have used for many years with successful results. We are on generation Paste 5, and it IS one of the very best performing pastes available on the world market..... it is sold to users all over the globe!

Thank you for your business,

Phil Andrew

Global CEO / VP

Inventor of IP system

admin@thewaterstaindoctor.co.nz

