



Nanocoat® Surface Treatment Care Instructions

Congratulations, you now have easy to clean glass. To keep your glass in top condition and under warranty - please follow the minimum maintenance instructions below.

NEW ZEALAND - AUSTRALIA - GLOBAL

Shower Units • Bath Screens

The Ultimate – Buff glass down **twice weekly** with a wet and dish wash liquid 'infused' micro-fibre cloth. Optionally dry down with a towel or dry microfibre cloth. **DO NOT** use a 'squidgy' plastic or rubber blade

A MUST DO – A **weekly** buff of the glass with a damp wetted micro-fibre cloth. A little low PH neutral dishwashing soap should be used (Palmolive, Sunlight or similar), we recommend the **WSD Nano Gel WIPE** provided **once per month**. (Usually **AFTER AN INITIAL 12-24 MONTHS**). Wipe your treated glass thoroughly then rinse down with fresh water. You can place the shower head or jug of water against the glass and move slowly left and right, starting at the top and moving down the glass; this will remove most of the water beads and leave you with almost totally dry glass. Or optionally dry down with a towel or chamois.

While you still must maintain your **Nanocoat®** coated surface, the time and effort required is significantly reduced. The higher your water 'hardness' (mineral count), the greater the surface tension and water/soap spotting. This means shower doors and bath screens require more maintenance than other applications.

The benefit of your **Nanocoat®** treated surfaces is that those spots, if removed every few days, will not stick and can be easily removed with a damp micro fibre cloth. **It also reduces calcium and mineral staining by up to 90%**

Exterior Windows • Balustrades

Dust, salt spray and dirt particles are washed off naturally by rain. Your windows can also be maintained by a professional window cleaner. For any remaining sticky deposits wipe down with a micro-fibre cloth and dish wash liquid (Palmolive or Sunlight Liquid). Dry with towel or chamois. It is recommended you use our exclusive **WSD Nano Gel WIPE** to maintain optimum clarity and cleanliness as well as RECHARGE the protection product to its optimum repellency on a monthly to 2 monthly basis, when in hard water and active salt spray regions.

Usually it is necessary to use detergent, and it must be LOW or a ph neutral detergent. But please note that any detergent creates a reduction of the ability of the water to bead off (due to a reduction of the surface tension of the water). After rinsing the surface with clear water the 'bead off' effect should return. If you do notice a build up of deposits or residue on the surface because it has not been maintained as outlined, wipe the glass with a Water Stain Doctor™ glass friendly abrasive sponge and '**WSD Nano Gel WIPE**' then rinse with fresh water. '**WSD Nano Gel WIPE**' does **NOT** GET USED until your PROTECTION shows signs of reduced repellency. Your days of using harsh cleaning products are over. The **Nanocoat®** coating is now part of the glass.

DO NOT:

- Scrub glass with abrasive pads i.e. green scotchbrite pads
- Leave your glass un-maintained for more than 7 days if in use
- Use ANY 'off the shelf' supermarket shower glass cleaners
- Use caustic based cleaners or other acid based products, which may affect the coating.
- Use a rubber or plastic 'squidgy' blade

DO:

- Enjoy the benefits of your **Nanocoat®** coated glass surfaces!



*This warranty **does NOT transfer to the Franchisor, Supplier or Manufacturer of the 'Nanotechnology product'**.
No claims may be made against the Franchisor under the terms of our license agreement with our applicators, or the DIY purchaser, and/or ends at the agency v client level.*